

J10 WALL MOUNTED HUMIDISTAT INSTALLATION INSTRUCTIONS 120 VOLT

1. Disconnect electrical power.
2. Determine humidistat location. This control should be mounted on an inside wall where normal air circulation can surround the control. For most residential applications, locate the control adjacent to the existing wall thermostat for easy installation and wiring.
3. Remove cover from back plate.
4. Connect flying leads from back of base plate to the power supply with approved wire connectors.
5. Mount back plate securely to the wall box with screws provided in the parts package.
Note : Make sure the back plate is flat without any undue stress.
Note: All wiring should conform to recommendations and any electrical codes.
6. Re-install front cover and secure with cover screw supplied in parts package.

OPERATIONAL TEST

Turn the humidistat down to its lowest then to its highest setting. Cycle at least 3 times to assure proper system function. Return control knob to the desired setting.

